





# GE.BD.660/600.BF+011

1500 rpm - Trifase - 50Hz - 400V Automatic panel without switching on board





Image for demonstration purposes

# **Standard equipment**

## Exhaust

Exhaust manifold protection Silenced muffler -15dB(A)

# Fuel Supply

Single wall daily tank with bunded base Fuel gauge

## **Handling**

n.4 lifting hooks integrated into the bearing structure

## Base Frame

Bunded base at 110% of fuel tank capacity Anti-vibrating mounting pads

# Engine

Engine pre-heater 230V

High coolant temperature and low oil pressure shutdown system

Oil pressure and coolant temperature gauge (only with QPE or +14 variant)

External oil drain points

Engine liquids (oil and antifreeze)

**Tropicalized radiator** 

Rotating parts protection

Electronic speed governor

Radiator level sensor

# Alternator

**AVR Automatic Voltage Regulator** AVR Pre-arranged for parallel Impregnation for marine environment

# Panel & connection

Emergency Stop button Magnetothermal circuit breaker on alternator board Cable output from side IP44 wiring Start-up battery (pre-charged) Grounding point

## Documentation

CE conformity declaration User and Maintenance manual Wirings diagrams

## Normatives

All Generating sets are compliant to CE Marking 2014/30/UE Electromagnetic compatibility 2000/14/CE Noise Emission for outdoor use Factory-designed systems built according to ISO 9001:2015 CEI EN 60204-1:2018 - Electrical equipment of machines















# **Primary data**

General Information

Speed	RPM 1	1500
Frequency	Hz 5	50
PRP	KVA 6	500
PRP - Prime power	KW 4	180,0
LTP - Standby power	KVA 6	560
LTP - Standby power	KW 5	528,0
Standard Voltage	V 4	400/230
Current	A 8	367,05
Voltage for current calculation	V 4	100
COSFI	0,8	0,8
General electrical protection  Rated current	A 1	1000
		1000 Wagnetothermal switch on the alternator board
Rated current	N	
Rated current Type Poles	N	Magnetothermal switch on the alternator board
Rated current Type	N 4	Magnetothermal switch on the alternator board
Rated current Type Poles Fuel Consumption	N 4	Magnetothermal switch on the alternator board
Rated current Type Poles Fuel Consumption TYPE	N 4	Magnetothermal switch on the alternator board  P  Diesel
Rated current Type Poles Fuel Consumption TYPE Standard Fuel Tank capacity	N 4  It 4  h 5	Magnetothermal switch on the alternator board  P  Diesel
Rated current Type Poles Fuel Consumption TYPE Standard Fuel Tank capacity Autonomy @ 75% load	N 4    N   A	Magnetothermal switch on the alternator board  P  Diesel  400

# 🕶 General data

Rated capacity	Ah	2x180
Auxiliary Voltage	V	24
Exhaust gas temperature	°C	600
Exhaust gas flow	l/s	1786
Combustion air flow	l/s	528
Cooling fan airflow	mc/s	13,3

# Weight and Dimensions

Dimensions (L x W x H)	cm	350x150x190
Weight with liquids (excluding optionals and fuel)	Kg (+/-3%)	4223







# Engine

Factory		Baudouin
Model		8M21G660/5
Emissions stage		Stage 0
Speed governor		Electronic
Radiator	°C	50
Cooling	Tipo	liquid (water + 50% Paraflu11)
Active net power	Kwm	498
Nominal net power	CV	668
Cycle	Tipo	4 strokes
Aspiration	Tipo	Turbo
Numbers of cylinders	N	8
Cylinders arrangement		v
Bore	mm	127
Stroke	mm	165
Total displacement	lt	16.72
Engine oil features		15W40-API CI-4/CH-4 ACEA E5-E7
Total oil capacity	lt	45
Total coolant capacity	lt	101
ISO 8528-5 class		G2

The emission levels of the exhaust gas are indicated in the engine technical datasheet. Any changes due to more restrictive regulatory adjustments are excluded.

# Alternator

## \* May vary based on stock availability. However, a primary brand will be used.

Factory		Stamford
Model		S5L1D-E
PRP continuous power	KVA	610
Voltage Regulator (voltage accuracy)	+/- %	1
Poles	N°	4
Phases	N°	3+N
Standard windings connection		Star Series Star Series
Stator/rotor impregnation		H (Outdoor Temp 40°C)
Efficiency	%	94,9
Engine coupling		Elastic disk
Short circuit current		>= 300% (3In)
Protection degree	IP	23
Cooling system		Self ventilating
Maxium overspeed	rpm	2250
Waveform distortion	%	<5
Exciter		Diode bridge

# Standard operating environmental conditions


Ambient temperature	°C	25
Relative Humidity	%	30
Max altitude	mt	1000





# **Control Systems on board QPE-C-SC-3F-V1**





#### operating scheme - schema di funzionamento

# 

The QPE-C control panel represents the evolution of the panel for the control and management of the gen set. With its microprocessor logic it is able to meet any user requested features. The dual operation mode manual and automatic guarantees to every type of functionality protection, analysis and control of the generating set in order to make the management easy and efficient. Variant without transfer switch on board. ATS panel type QC as optional. The panel manages the QC panels directly or any other ATS panel.

# Mechanical features

Protection degree	IP	55

# Battery charger

Model		ELCOS - CB1
Maximum output current	Α	2,5
Output DC voltage (selectable)	Vdc	12-24
Input AC voltage (selectable)	Vac	220-260
Frequency	Hz	50-60

# Data Communication

Data connection port	RS-485
Communication protocol	Mod-bus RTU-8N1

# Remotable functions in terminal box

GS start
Genset contactor close/open command (1)
Common Alarm - DC output
GS start with key in OFF position (Only in MRS mode)

GS lock
Mains contactor close/open command (2)
GS test without load
Programmable output - Volt free output







#### Model MC4 AMF - MRS Operating mode

### **Specifics**

**Applications** 

Emergency to the Mains Stand-alone Construction site/Rental Self-production

**ENGINE MEASURES** 

Fuel tank level %

Engine oil pressure BAR (1)

Engine Coolant temperature °C (1)

Total run time

Partial run time

Hours to maintenance

Battery voltage

Battery charging voltage

Start-ups counter

Engine speed (2)

Engine Oil temperature (2)

Cooler temperature (2)

Engine oil level (2) Engine coolant level (2)

Engine coolant pressure (2)

Turbo pressure (2)

Fuel Consumption (2)

Tank autonomy - hrs (5)

Fuel remaining quatity (5)

Fuel used quantity (5)

#### **ALTERNATOR MEASURES**

Generator Voltage L1, L2, L3

Generator Voltage L1-N, L2-N, L3-N

Generator frequency

Generator current L1, L2, L3

Generator Apparent Power kVA Generator Active Power kW

Generator Reactive Power kVAR

Generator accumulated power kWh

Power factor Cosfi

### **MAINS MEASURES**

Mains voltage L1, L2, L3

Mains voltage L1-N, L2-N, L3-N

Mains frequency

## **COMMUNICATION PORTS**

Can-bus port

RS485 port with Mod-bus RTU communication

RS232 port for display connection

USB port for parameters saving and firmware

update

**EQUIPMENT** 

Microprocessor Logic

Back-lit display

Programmable from display

16 event log

Multiple display languages

STOP button

START button

TEST button

Reset alarm button

Alarm mute button

Fuel transfer pump activation button

Glow-plug activation button

#### PRE-ALARMS/ ALARMS

Common Alarm

Fuel reserve (pre-alarm)

Low fuel level (alarm)

Tank overflow

Charge alternator failed (dinamo)

Low oil pressure (pre-alarm) (1)

Low oil pressure (alarm)

Oil sensor failed (alarm)

High coolant temperature (pre-alarm) (1)

High coolant temperature (alarm)

Low coolant temperature (pre-alarm)

Low water level (1) Water in fuel (1)

Battery undervoltage

Battery overvoltage

GS failure to start

GS failure to stop

Can-bus Failure

No Can-bus communication

Genset overload L1, L2, L3 phases

Genset short circuit

Genset overvoltage

Genset undervoltage

Genset high frequency

Genset low frequency

overspeed

Reverse power

Earth fault (pre-alarm)

Earth fault (alarm) Block from password

CAN communication Failed

Maintenance request

Emergency button pressed

Remote emergency active

Forced stop

External battery failed

Fuel theft

Genset negative phase sequence

Mains negative phase sequence

Fuel theft protection

VISUALIZATIONS ON CONTROL MODULE/DISPLAY

Pre-alarms

Alarms

Engine measures

Alternator measures

Mains measures

Date and time

Operating mode Genset status

Mains status

Mains contactor status

Genset contactor status

Digital Input and Output status

Grounding current mA (3)

Grounding current threshold mA (3)

Delay time of differential protection (3) Glow plugs status

**CONTROL MODULE FUNCTIONS** 

Automatic start and stop when the Mains Fails (7)

Remote Start and Stop

Remote Start and Stop with key in OFF position

Manual Start and stop

Emergency stop button on panel board

Remote emergency stop

Remote lock

Remote test without load

Remote test on load

Scheduled start-ups

MODBUS commands (Start, Stop, Reset, Test)

#### **CONTROL MODULE SPECIAL FUNCTIONS** (on demand)

Automatic charging of an external battery

Dummy load (4)

Load shedding (4) Redundant starter motor management

Fuel monitoring

GS battery Load test

Idle mode Service phone number indication

Variable speed Generator

Master / Slave mode

(1) Present with the sensor installed on engine

(2) Present according to the engine equipment and to the ECU type (ECU - Canbus) (3) Present only with the residual current device mounted on genset board

(4) Present with optional expansion modules

(5) Present with special function activated

(6) Only with the optional of the automatic fuel refilling system on board

(7) Only in AMF mode



# **OPTIONAL**

# Fuel Supply



O.G-ACO-AT-C3V-02 External fuel tank connections with 3-way valve for supply from internal or external tank (130/700 kVA)



O.G-ACO-AT-CI-02 External tank connections for supply only from external tank (g without tank) GE 130/700



**O.G-ACO-ST-BG-ES1** "Easy" automatic fuel refilling system on board, controlled by QPE-C and QLE-B panels

O.G-ACO-ST-BG-HDT

"Heavy Duty" automatic fuel refilling system on board, controlled by QPE-C and QLE-B panels



**O.G-ACO-ST-BG-STD** "Standard" automatic fuel refilling system on board, controlled by QPE-C and QLE-B panels

### Electrical on board



O.Q-QPE-485.CONV-LAN

Converter 485/LAN for QPE-C, QLE-B panel



O.Q-QPE-485.CONV-USB

Converter 485/USB for QPE panel

O.Q-QPE-DIS-MS.01

MASTER/SLAVE device for QPE panel

O.Q-QPE-K-DIF

Differential protection adjustable for the MC4

O.Q-QPE-MD-QPE-C

GSM remote management modem for QPE panel



O.Q-QPE-PR-QPE-C

Remote panel for QPE-C, QLE-B - available only for variant +10/+11



O.Q-QPE-QBM-COM-AMF25

Option with QBM COMAP AMF25 controller on board instead of QPE



O.Q-QPE-QBM-DSE-7320

Option with QBM DSE7320 controller on board instead of QPE.



O.Q-QPE-RIL-16RELE

16-relay module for QPE panel



O.Q-QPE-RX8-QPE-C

Start-stop radio control with max. radius 500 mt indoors and 5 km outdoors (for QPE panel).



O.Q-QPE-SAS-02

Auto Start-Stop at load request (QPE, QLE panels)



O.Q-QPE-SCD-01

Anti-condensation heater inside the panel





O.Q-QPE-SEL-50-60

Switch selector 50Hz 400V / 60Hz 480V



O.Q-QPE-TG-EVO-GPS-4G

Remote management system via LAN/GSM 4G with WEB application and GPS location system



O.Q-QPE-TG-QPE-C

Remote management software via LAN for QPE-C, QLE-B panel compatible with Windows XP and 7





O.G-MOT-K-40C-05

Engine liquids suitable for -40°C ambient temperature for Gen Sets 450/700 kVA



O.G-MOT-PO-02

Oil change pump for Gen Sets 130/700 kVA



O.G-MOT-SC-AC-EL-04

Super hot engine heater 230V with thermostat on board for Gen Sets 275/700 kVA



O.G-MOT-SE-LR-02

Radiator coolant level sensor from 130 to 700 kVA

### ATS Panels



QC3.1250A

Separate ATS panel, ABB 1250A motorized change-over (800 kVA 400V) Dim.  $80 \times 60 \times 160$  cm - 220 kg. (ex QC3.800)

## Exhaust



O.G-SCA-MR-07

Residential muffler -35 dBA (450/700 kVA)



O.G-SCA-PF-05

Spark arrestor for Gen Sets 450/700 kVA

### **PRP**


Engines of this rating provide unlimited hours of usage in a variable load application. The average load factor should not exceed 70% of the engine's prime power rating with a maximum number of 500 operational hours at 100% prime power rating. An overload capability of 10% is available, however, is limited to a period of 1 in every 12 hours

### LTP

Limited-time running power is defined as the maximum power available, under the agreed operating conditions, for which the generating set is capable of delivering for up to 500h of operation per year with the maintenance intervals. The overload is not allowed.




₩ GE.BD.660/600.ST.BF+011







₩ GE.BD.660/600.ST.BF+011



Front

Rear

Left

## VENTILATION OF THE ROOM

The windows area in the generating set room needs to be (recommended):

Aspiration: on request Expulsion: on request

ATTENTION: for a correct ventilation the expulsion air and the exaust gas needs to be conveyed in the open-air

IMPORTANT:

- 1) Form and dimension refer to the generating set on catalogue
- 2) Form and dimension are subject to change in order to update or improve the products
  3) This document can not be copied or trasmitted without ELCOS S.r.l. approval